

DETAILS OF FLOOD FORECASTING STATIONS IN ANDHRA PRADESH UNDER GODAVARI BASIN

S.NO	FF STATION	RIVER	BASE STATION	WARNING LEVEL (m)	DANGER LEVEL (m)	TRAVEL TIME(hrs)	TYPE OF DATA BEING USED FOR FORMULATION
INFLOW FORECAST STATIONS							
1	SREERAMASAGAR	GODAVARI	NANDED	332.54	333.15	24	RAINFALL, QPF
			NIZAMSAGAR	FRL	MWL		STAGE, DISCHARGE
			DEGLOOR	1091 FEET	1093 FEET		
2	NIZAMSAGAR	MANJIRA	SINGUR (OUTFLOW)	428.24	429.24	24	RAINFALL
				1404.99 (Ft)	1404.99 (Ft)		
				FRL	MWL		
3	SINGUR	MANJIRA	NIZAMSAGAR	523.60	523.60	24	RAINFALL
			SINGUR	FRL	MWL		
4	JAIKWADI	GODAVARI	Dharna Dam, NMD,	463.91	465.5		RAINFALL
			Mula dam, Lasur, AGD	1522 ft	1527.0(ft)	24	
LEVEL FORECAST STATIONS							
1	KOPARGAON	GODAVARI	NMD WEIR	490.9/5.40	493.68 / 8.18	18	PEAK TO PEAK AND RAINFALL
							RAINFALL, QPF
2	GANGAKHED	GODAVARI	DHALEGAON	374.00	375.00	18	STAGE, DISCHARGE
3	NANDED	GODAVARI	GANGAKHED, PURNA	353.00 / 12.50	354.00/13.50	12	RAINFALL, QPF
							STAGE, DISCHARGE
4	BALHARSHA	WARDHA	HIVRA, P.G.BRIDGE, NANDAGAON	171.50 / 13.53	174.00 / 16.03	18-30	RAINFALL, QPF
							STAGE, DISCHARGE

S.NO	FF STATION	RIVER	BASE STATION	WARNING LEVEL (m)	DANGER LEVEL (m)	TRAVEL TIME (HRS)	TYPE OF DATA BEING USED	
							FOR FORMULATION	
5	BHANDARA	WAINGANGA	BALAGHAT,	244.00/9.00	244.50 / 9.50	15-18	RAINFALL, QPF	
			RAJEGAON				STAGE, DISCHARGE	
6	PAUNI	WAINGANGA	BHANDARA	226.73	227.73	06-09	RAINFALL, QPF	
							STAGE, DISCHARGE	
7	JAGDALPUR	INDRAVATH I	NOWRANGPUR,	539.50/7.00	540.80 / 8.30	15-18	RAINFALL, QPF	
			KOSAGUMDA				STAGE, DISCHARGE	
8	KALESWARAM	GODAVARI	MANCHERIAL,	103.50	104.75	18	RAINFALL, QPF	
			BALHARSHA				STAGE	
9	ETURUNAGARAM	GODAVARI	KALESWARAM,	I- 73.29	75.79	12-18	STAGE, RAINFALL, QPF	
			PATHAGUDEM	II-74.29				
10	DUMMAGUDEM	GODAVARI	PERUR	53.00	55.00	12-15	STAGE, DISCHARGE RAINFALL, QPF	
11	BHADRACHALAM	GODAVARI	PERUR	I- 45.72	48.77	15-18	STAGE, DISCHARGE RAINFALL, QPF	
				I- 43 FEET			53 FEET	
				II-47.24				
				II-48 FEET				
12	KUNAVARAM	GODAVARI	PERUR	37.74	39.24	12-18	STAGE, DISCHARGE RAINFALL, QPF	
13	RAJAHMUNDRY	GODAVARI	BHADRACHALAM ,	17.68	19.51	15-18	STAGE, RAINFALL, QPF	
			KONTA					
14	DOWLAI SWARAM	GODAVARI	BHADRACHALAM ,	I-14.25	16.08	15-18	STAGE, RAINFALL, QPF	
			KONTA	II-14.86				

DETAILS OF WIRELESS STATIONS IN GODAVARI BASIN

Sl. No.	Name	River	Latitude	Longitude	Remarks
1	Gangapur Dam	Godavari	Wireless station maintained by Maharashtra State Govt.		
2	Nasik	Godavari	20	73	
3	Dharna Dam	Dharna	Wireless station maintained by Maharashtra State Govt.		
4	Palkhed	Kadawa	20	73	R/G BS
5	N.M. Weir	Godavari	19-56-43	74-19-59	R/G BS
6	Kopergaon	Godavari	19-54	74-30	R/G FS
7	Pachegaon	Pravara	19-32	74-52	R/G/D BS
8	Lasur	Shiv	19-30-15	74-57-30	R/G BS
9	Jaikwadi Dam	Godavari	19-28	75-23-31	R/G FS
10	Dhalegaon	Godavari	19-13-10	76-21-49	R/G/D BS
11	Gangakhed	Godavari	18-58-15	76-46-13	R/G FS
12	Zari	Dudhna	19-23-41	76-46-24	RGDBS
13	Purna	Purna	40501	77-02	R/G/D BS
14	Nanded	Godavari	40805	77-20-34	R/G FS
15	Saigon	Manjira	36603	77-03	R/G/D BS
16	Singur	Manjira	17-45	77-56	
17	Nizamsagar	Manjira	18/12/2020	77-55-30	
18	Degloor	Lendi	18-32-44	77-34-39	
19	Bhainsa	Siddhavagu	40317	77-58	
20	Mancherial	Godavari	18-51-01	79-26-40	
21	Aurangabad		19-51	75-10	
22	Nizamabad		18-38-57	78-06-05	
23	Sriramsagar	Godavari	18-55	78-20	
24	P.G.Bridge	Penganga	19-49	78-34	

25	Bhatpalli	Peddavagu	19-18-47	79-27-57	
26	Hivra	Wardha	20-32-49	78-19-36	
27	Nandgaon	Wunna	20-31-00	78-46-26	
28	Ghugus	Wardha	19-56	79-06	
29	Balharsha	Wardha	19-48	79-22	
30	Balaghat	Wainganga	21-52-57	80-10-38	
31	Rajegaon	Bagh	21-37-16	80-14-14	
32	Sitakesa	Bawanthadi	21-35	79-48	
33	Bhandara	Wainganga	21-Oct	79-40	
34	Ramakona	Kanhan	21-43-08	78-49-24	
35	K.R.Bridge	Kanhan	21-13-08	79-13-58	
36	Pauni	Wainganga	20-49	79-39	
37	Ashti	Wainganga	19-41	79-47	
38	Tekra	Pranhita	18-57	79-58	
39	Nagpur Air Port		40350	79-03	
40	Chandrapur		19-58	79-18	
41	Nowrangpur	Indravathi	19-13-36	82-32-24	
42	Kosagumda	Bhaskal	19-16-37	82-14	
43	Jagdapur	Indravathi	40317	82-03	
44	Chindnar	Indravathi	40317	81-18	
45	Tumnar	Dantewada	19-00-30	81-14-20	
46	Pathagudem	Indravathi	18-42	80-18	
47	Kaleswaram	Godavari	18-48-33	79-54-48	
48	Perur	Godavari	18-33	80-22	
49	Eturunagaram	Godavari	18-21	80-26	
50	Dummagudem	Godavari	17-50	80-54	
51	Bhadrachalam	Godavari	17-39-57	80-53-02	
52	Sangam	Kinnersani	17-36	80.49	

53	Saradaput	Sabari	18-36	82-08	
54	Sukma	Sabari	18-24	81-42	
55	Konta	Sabari	17-48	81-23	
56	Kunavaram	Godavari	17-36	81-18	
57	Koida	Godavari	17-29-15	81-23-15	
58	Polavaram	Godavari	17-15	81-40	
59	Rajahmundry	Godavari	16-57-59	81-46-59	
60	Dowlaiswaram	Godavari	16-58	81-47	
61	Keolari	Wainganga			